

INSTALLATION INSTRUCTIONS

Part Number HA-1191

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made, tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N Filtercharger® seals properly.

INSTALLATION

1. Remove the stock air filter.
2. Carefully clean the inside of the air box.
3. Install the provided foam pre-filter onto the outside of the K&N Filtercharger®.

NOTE: On an unmodified motorcycle the foam pre-filter must be used and should not be oiled.

NOTE: For maximum airflow, the foam pre-filter can be removed. Recalibration of the carburetors will be required.

4. Install the K&N Filtercharger® in the air box.
5. Reinstall the air box lid.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.